

Vehicle Support Matrix

Make / Model	MAN TGA 2002	MAN TGL/TGM/TGA 2005	MAN TGL/TGM/TGA/TGX 2007
Vehicle Speed	●	●	●
Brake switch	●	●	●
Clutch Switch	●	●	●
PTO state	●	●	●
Accelerator Pedal Position	●	●	●
Engine Speed (RPM)	●	●	●
<hr/>			
Total fuel used	●	●	●
Total distance travelled	●	●	●
Service Distance	●	●	●
Engine Hours	●	●	●
Engine temperature	●	●	●
Fuel Level (dashboard)	●	●	●
<hr/>			
Tachograph vehicle speed	●	●	●
Tacho working states	●	●	●
Tacho direction	●	●	●
Tacho performance	●	●	●
Tacho Driver ID	●	●	●
Axle weight	●	●	●
VehicleID	●	●	●
<hr/>			
Turbo Pressure	●	●	●
Actual Fuel	●	●	●
Actual Engine Torque	●	●	●
Oil Pressure	●	●	●
Coolant level	●	●	●
<hr/>			
Brake pressure, ABS, EBS Info	●	●	●
Automatic Gear Info	●	●	●
Retarder Info	●	●	●
Kickdown	●	●	●

Remarks

All TGA version. Pre 2002 TGA models inaccurate

All models Euro3 and above

All models Euro3 and above

Cable for direct connect

6693-U2

6693-U2

6693-U2

Cable for FMS connect

6692-U2

6692-U2

6692-U2

Installation instruction for direct connect

MAN Direct

MAN Direct

MAN Direct

Installation instruction for FMS

MAN KSM

MAN KSM

MAN KSM

● Supported

● Truck Config Dependant

Scan files

MAN direct

MAN direct

MAN direct

DCF for CANdiode

standard

standard

standard

DCF for iCommDiode

standard

standard

standard

DCF for iCommunicate

standard

standard

standard

Vehicle Support Matrix

Make / Model	DAF XF95 2000	DAF CF/LF/XF 2001	DAF CF/LF/XF105 2006
Vehicle Speed	●	●	●
Brake switch	●	●	●
Clutch Switch	●	●	●
PTO state	●	●	●
Accelerator Pedal Position	●	●	●
Engine Speed (RPM)	●	●	●
<hr/>			
Total fuel used	●	●	●
Total distance travelled	●	●	●
Service Distance	●	●	●
Engine Hours	●	●	●
Engine temperature	●	●	●
Fuel Level (dashboard)			●
<hr/>			
Tachograph vehicle speed		●	●
Tacho working states		●	●
Tacho direction		●	●
Tacho performance		●	●
Tacho Driver ID			●
Axle weight		●	●
VehicleID	●	●	●
<hr/>			
Turbo Pressure	●	●	●
Actual Fuel	●	●	●
Actual Engine Torque	●	●	●
Oil Pressure			●
Coolant level			●
<hr/>			
Brake pressure, ABS, EBS Info		●	●
Automatic Gear Info		●	●
Retarder Info		●	●
Kickdown		●	●
<hr/>			
Remarks	95XF Euro3 production 2002/37 to 41	Euro3 models LF: >0L253000 CF: >0E553000 XF: >0E592560	Euro4 and 5 models LF CF XF105
<hr/>			
Cable for direct connect	6693-U2	6693-D1	6693-D1
Cable for FMS connect	No DAF FMS unit available	6692-D1	6692-D2
<hr/>			
Installation instruction for direct connect	DAF95XF	DAF direct LF/CF/XF	DAF direct LF/CF/XF
Installation instruction for FMS	No DAF FMS unit available	DAF FMS LF/CF/XF	DAF FMS LF/CF/XF105 Euro4-5
<hr/>			
		● Supported	● Truck Config Dependant

Vehicle Support Matrix

Make / Model	Scania 4 serie 1995-1999	Scania 4 serie 1999-2004	Scania R-P serie 2005 +
Vehicle Speed	●	●	●
Brake switch	●	●	●
Clutch Switch	●	●	●
PTO state	●	●	●
Accelerator Pedal Position	●	●	●
Engine Speed (RPM)	●	●	●
Total fuel used	●	●	●
Total distance travelled	●	●	●
Service Distance	●	●	●
Engine Hours	●	●	●
Engine temperature	●	●	●
Fuel Level (dashboard)			●
Tachograph vehicle speed		●	●
Tacho working states		●	●
Tacho direction		●	●
Tacho performance		●	●
Tacho Driver ID			●
Axle weight			●
VehicleID	●	●	●
Turbo Pressure	●	●	●
Actual Fuel	●	●	●
Actual Engine Torque	●	●	●
Oil Pressure			●
Coolant level			●
Brake pressure, ABS, EBS Info	●	●	●
Automatic Gear Info	●	●	●
Retarder Info	●	●	●
Kickdown	●	●	●
Remarks	pre 2000 models 220, 310, 360, 400 HP without EDC are not supported Models pre 2001 can have inaccurate data	All models	All models
Cable for direct connect	6693-S1	6693-S1	6693-S2
Cable for FMS connect	6692-S1	6692-S1	6692-S1
Installation instruction for direct connect	Scania Direct 4 series	Scania Direct 4 series	Scania Direct P-R series
Installation instruction for FMS	Scania FMS 4 series	Scania FMS 4 series	Scania FMS P-R series

● Supported
● Truck Config Dependant

Vehicle Support Matrix

Make / Model	Iveco Eurocargo 2001	Iveco Stralis 2002	Iveco Trakker 2004	Iveco Stralis 2006
Vehicle Speed	●	●	●	●
Brake switch	●	●	●	●
Clutch Switch	●	●	●	●
PTO state	●	●	●	●
Accelerator Pedal Position	●	●	●	●
Engine Speed (RPM)	●	●	●	●
<hr/>				
Total fuel used	●	●	●	●
Total distance travelled	●	●	●	●
Service Distance	●	●	●	●
Engine Hours	●	●	●	●
Engine temperature	●	●	●	●
Fuel Level (dashboard)	●	●	●	●
<hr/>				
Tachograph vehicle speed	●	●	●	●
Tacho working states	●	●	●	●
Tacho direction	●	●	●	●
Tacho performance	●	●	●	●
Tacho Driver ID	●	●	●	●
Axle weight	●	●	●	●
VehicleID	●	●	●	●
<hr/>				
Turbo Pressure	●	●	●	●
Actual Fuel	●	●	●	●
Actual Engine Torque	●	●	●	●
Oil Pressure				
Coolant level				
<hr/>				
Brake pressure, ABS, EBS Info	●	●	●	●
Automatic Gear Info	●	●	●	●
Retarder Info	●	●	●	●
Kickdown	●	●	●	●
<hr/>				
Remarks	Only for EDC type engines after 3-1993	All models Euro3	All models Euro3 Since Nov 2004	All models Euro 4-5 Since July 2006
<hr/>				
Cable for direct connect	6693-i1	6693-i1	6693-i1	6693-i1
Cable for FMS connect	6692-d1	6692-i1	6692-i1	6692-i2
<hr/>				
Installation instruction for direct connect	Iveco EuroCargo Direct	Iveco Stralis Euro3 Direct	Iveco Stralis Euro3 Direct	Iveco Stralis Euro4/5
Installation instruction for FMS	Iveco EuroCargo FMS	Iveco Stralis Euro3 FMS	Iveco Stralis Euro3 FMS	Iveco Stralis Euro4/5 FMS

● Supported
● Truck Config Dependant

Vehicle Support Matrix

Make / Model	Mercedes Atego 1998	Mercedes Atego 2004	Mercedes Actros MP1 1996+	Mercedes Actros MP2 2003+	Mercedes AXOR 2001+
Vehicle Speed	●	●	●	●	●
Brake switch	●	●	●	●	●
Clutch Switch	●	●	●	●	●
PTO state	●	●	●	●	●
Accelerator Pedal Position	●	●	●	●	●
Engine Speed (RPM)	●	●	●	●	●
<hr/>					
Total fuel used		●	●	●	●
Total distance travelled	●	●	●	●	●
Service Distance	●	●	●	●	●
Engine Hours	●	●	●	●	●
Engine temperature	●	●	●	●	●
Fuel Level (dashboard)	●	●	●	●	●
<hr/>					
Tachograph vehicle speed	●	●	●	●	●
Tacho working states	●	●	●	●	●
Tacho direction	●	●	●	●	●
Tacho performance	●	●	●	●	●
Tacho Driver ID					
Axle weight		●	●	●	●
VehicleID	●	●	●	●	●
<hr/>					
Turbo Pressure	●	●	●	●	●
Actual Fuel		●	●	●	●
Actual Engine Torque	●	●	●	●	●
Oil Pressure					
Coolant level					
<hr/>					
Brake pressure, ABS, EBS Info					
Automatic Gear Info					
Retarder Info			●	●	●
Kickdown					
<hr/>					
Remarks	Please check baumuster: 375/930-934, 944, 950-954, 957, 970-976 these baumusters can support COTEL (FMS), please order PSM version 3 diagnose 6 or higher if it is not a MP2 engine.				
	Requires JK3 option				
<hr/>					
Cable for direct connect	6693-U2	6693-U2	6693-U2	6693-U2	6693-U2
Cable for FMS connect	6692-B1	6692-B1	6692-B1	6692-U2	6692-B1
<hr/>					
Installation instruction for direct connect	Mercedes Direct	Mercedes Direct	Mercedes Direct	Mercedes Direct	Mercedes Direct
Installation instruction for FMS	Mercedes FMS	Mercedes FMS	Mercedes FMS	Mercedes FMS	Mercedes FMS

● Supported
● Truck Config Dependant

Vehicle Support Matrix

Make / Model	Renault Premium 2003	Renault Premium Avantage 2006	Renault Magnum 2003	Renault Magnum Avantage 2006	Renault Midlum 2006
Vehicle Speed	●	●	●	●	●
Brake switch	●	●	●	●	●
Clutch Switch	●	●	●	●	●
PTO state	●	●	●	●	●
Accelerator Pedal Position	●	●	●	●	●
Engine Speed (RPM)	●	●	●	●	●
<hr/>					
Total fuel used	●	●	●	●	●
Total distance travelled	●	●	●	●	●
Service Distance	●	●	●	●	●
Engine Hours	●	●	●	●	●
Engine temperature	●	●	●	●	●
Fuel Level (dashboard)	●	●	●	●	●
<hr/>					
Tachograph vehicle speed		●	●	●	●
Tacho working states		●	●	●	●
Tacho direction		●	●	●	●
Tacho performance		●	●	●	●
Tacho Driver ID					
Axle weight		●	●	●	●
VehicleID	●	●	●	●	●
<hr/>					
Turbo Pressure	●	●	●	●	●
Actual Fuel	●	●	●	●	●
Actual Engine Torque	●	●	●	●	●
Oil Pressure					
Coolant level					
<hr/>					
Brake pressure, ABS, EBS Info					
Automatic Gear Info	●	●	●	●	●
Retarder Info	●	●	●	●	●
Kickdown	●	●	●	●	●
<hr/>					
Remarks	All models Euro3 with chassisnr starting 622	All models with chassisnr starting 627	All models Euro3 with chassisnr starting 611	All models with chassisnr starting 617	All models with DXI engine
Cable for direct connect	6693-V1	6693-V1	6693-V1	6693-V1	6693-V1
Cable for FMS connect	6692-V1	6692-V1	6692-V1	6692-V1	6692-V1
Installation instruction for direct connect	Renault Premium Direct	Renault Premium Avantage Direct	n/a	Renault Premium Avantage Direct	n/a
Installation instruction for FMS	Renault Premium FMS	Renault Premium FMS	Renault Magnum FMS	Renault Magnum FMS	Renault Premium FMS

● On J1587

● Supported
● Truck Config

Vehicle Support Matrix

Make / Model	Volvo FM/FH 1998-2001	Volvo FM/FL/FH 2001-2005	Volvo FE/FM/FL/FH16 2006+
Vehicle Speed	●	●	●
Brake switch	●	●	●
Clutch Switch	●	●	●
PTO state	●	●	●
Accelerator Pedal Position	●	●	●
Engine Speed (RPM)	●	●	●
<hr/>			
Total fuel used	●	●	●
Total distance travelled	●	●	●
Service Distance	●	●	●
Engine Hours	●	●	●
Engine temperature	●	●	●
Fuel Level (dashboard)	●	●	●
<hr/>			
Tachograph vehicle speed	●	●	●
Tacho working states	●	●	●
Tacho direction	●	●	●
Tacho performance	●	●	●
Tacho Driver ID	●	●	●
Axle weight	●	●	●
VehicleID	●	●	●
<hr/>			
Turbo Pressure	●	●	●
Actual Fuel	●	●	●
Actual Engine Torque	●	●	●
Oil Pressure	●	●	●
Coolant level	●	●	●
<hr/>			
Brake pressure, ABS, EBS Info	●	●	●
Automatic Gear Info	●	●	●
Retarder Info	●	●	●
Kickdown	●	●	●

Remarks

All models with engine type D12C an above, build from 1998-2002. ** Identification of engineType see chassinumber postion 5,6,7,=
4DG,4DE,4DF,4DP,4DR,4DM,4DH,4DC,4DA,4DK,4DD, 4DB,4DL,5AC,4CL,4CM,
4CF,4CE,4CD,4EM,4EP,4ER, 4EA,4EB,4EC,4ED,8A1,8A2, after 2002 all models!

Cable for direct connect	6693-V1	6693-V1	6693-V1
Cable for FMS connect	6692-V1	6692-V1	6692-V1
Installation instruction for direct connect	Volvo Direct	Volvo Direct	Volvo Direct / Volvo FE Direct
Installation instruction for FMS	Volvo FMS	Volvo FMS	Volvo FMS

● Supported
● On J1587
● Truck Config Dependant

Vehicle Support Matrix

Make / Model	Cummins QSX 2000	Cummins QSB 2000	Cummins QSK 2000
Vehicle Speed			
Brake switch			
Clutch Switch			
PTO state			
Accelerator Pedal Position	●	●	●
Engine Speed (RPM)	●	●	●
Total fuel used	●	●	●
Total distance travelled	●	●	●
Service Distance	●	●	●
Engine Hours	●	●	●
Engine temperature	●	●	●
Fuel Level (dashboard)			
Tachograph vehicle speed			
Tacho working states			
Tacho direction			
Tacho performance			
Tacho Driver ID			
Axle weight			●
VehicleID	●	●	●
Turbo Pressure	●	●	●
Actual Fuel	●	●	●
Actual Engine Torque	●	●	●
Oil Pressure	●	●	●
Coolant level	●	●	●
Brake pressure, ABS, EBS Info			
Automatic Gear Info			
Retarder Info			
Kickdown			

Remarks

Data can also be made available over J-bus/J1587

Data can also be made available over J-bus/J1587

Data can also be made available over J-bus/J1587

- Truck Configuration dependant
- Supported

Vehicle Support Matrix

Make / Model	Caterpillar	Caterpillar	Caterpillar
Vehicle Speed			
Brake switch			
Clutch Switch			
<hr/>			
PTO state			
Accelerator Pedal Position	●	●	●
Engine Speed (RPM)	●	●	●
<hr/>			
Total fuel used	●	●	●
Total distance travelled	●	●	●
Service Distance	●	●	●
<hr/>			
Engine Hours	●	●	●
Engine temperature	●	●	●
Fuel Level (dashboard)			
<hr/>			
Tachograph vehicle speed			
Tacho working states			
Tacho direction			
<hr/>			
Tacho performance			
Tacho Driver ID			
Axle weight			●
<hr/>			
VehicleID	●	●	●
Turbo Pressure	●	●	●
Actual Fuel	●	●	●
<hr/>			
Actual Engine Torque	●	●	●
Oil Pressure	●	●	●
Coolant level	●	●	●
<hr/>			
Brake pressure, ABS, EBS Info			
Automatic Gear Info			
Retarder Info			
<hr/>			
Kickdown			

Remarks

Data can also be made available over J-bus/J1587

Data can also be made available over J-bus/J1587

Data can also be made available over J-bus/J1587

- Truck Configuration dependant
- Supported

Make / Model	Iveco Daily 2001+	Iveco Daily 2006+
Vehicle Speed	●	●
Brake switch	●	●
Clutch Switch	●	●
PTO state		
Accelerator Pedal Position	●	●
Engine Speed (RPM)	●	●
Total fuel used	●	●
Total distance travelled	●	●
Service Distance	●	●
Engine Hours	●	●
Engine temperature	●	●
Fuel Level (dashboard)		
Tachograph vehicle speed		
Tacho working states		
Tacho direction		
Tacho performance		
Tacho Driver ID		
Axle weight		
VehicleID	●	●
Turbo Pressure	●	●
Actual Fuel	●	●
Actual Engine Torque	●	●
Oil Pressure		
Coolant level		
Brake pressure, ABS, EBS Info	●	●
Automatic Gear Info	●	●
Retarder Info		
Kickdown	●	●

Remarks

Remarks	All models with EDC engine Euro3 Since Nov 2001	All models with Euro4-5 Since Nov 2006
Cable for direct connect	6693-U2	6693-U2
Cable for FMS connect	No FMS available	No FMS available
Installation instruction for direct connect	Iveco Daily Euro3 Direct	Iveco Daily Euro4 Direct
Installation instruction for FMS	No FMS available	No FMS available

● Supported ● Supported
● Truck Config Dependant ● Truck Config Dependant

Vehicle Support Matrix

Make / Model	Mercedes VITO	Mercedes Sprinter
Vehicle Speed	●	●
Brake switch	●	●
Clutch Switch	●	●
PTO state		
Accelerator Pedal Position	●	●
Engine Speed (RPM)	●	●
<hr/>		
Total fuel used	●	●
Total distance travelled	●	●
Service Distance	●	●
Engine Hours	●	●
Engine temperature	●	●
Fuel Level (dashboard)	●	●
<hr/>		
Tachograph vehicle speed		
Tacho working states		
Tacho direction		
Tacho performance		
Tacho Driver ID		
Axle weight		
VehicleID	●	●
<hr/>		
Turbo Pressure	●	●
Actual Fuel	●	●
Actual Engine Torque	●	●
Oil Pressure		
Coolant level		
<hr/>		
Brake pressure, ABS, EBS Info		
Automatic Gear Info		
Retarder Info		
Kickdown		
Remarks	All models CDI since 2003	All models CDI since 2003
Cable for direct connect	6693-MS	6693-MS
Cable for FMS connect	6692-B1	6692-B1
Installation instruction for direct connect	Mercedes Sprinter Direct	Mercedes Sprinter Direct
Installation instruction for FMS	Mercedes Sprinter FMS	Mercedes Sprinter FMS

